

41 Cockpit Motor Yacht Setup

1. Install props.
2. Remove tape and clean the areas where the bridge will set. Check for voids along the top of the windows.
3. Apply sealant (732 white multi-purpose sealant) around deck bolts.
4. Lifting points for the bridge are between the two stand-offs on the forward bridge rail and two lifting eyes on the forward part of the aft deck hardtop. Position bridge over boat. Run the appropriate wires to the aft port corner; and run the drain line, water line, and appropriate wires to the aft starboard corner.
5. Set bridge in place, making sure that no wires or hoses get caught or pinched off. Make sure the bridge is pushed all the way forward.
6. With the bridge in place, bolt it down:
 - a. Five bolts under helm.
 - b. One bolt on each side aft.
7. Install exterior seating on bridge.
8. Install mast light and TV antenna on arch.
9. Connect all dash wiring and wet bar hoses in the aft starboard corner.
10. Install the port and starboard wing door frames (leave them loose). Use a small amount of Tef Gel on each fastener.
11. Slide the hardtop into place and secure it, using the hardware provided, to the arch and wing door frames.
12. Install the aft hardtop support legs.
13. Tighten all fasteners.
14. Install the arch-to-hardtop glass.
15. Cosmetically seal around the wing door frames and hardtop-to-arch connectors, and the back edges of the bridge.
16. Install the aft deck seating.
17. Use adhesive and two-sided tape to install the wing door windows. Try to clamp and let set overnight.



Lifting Bridge

Note the lifting points: between the two stand-offs on the forward bridge rail and two lifting eyes on the forward part of the aft deck hardtop.

Lifting Bridge

Side view.



Forward Bridge

Apply sealant around five deck bolts.



Aft Port Bridge

Apply sealant around deck bolt. Note wire run.

Aft Starboard Bridge

Apply sealant around deck bolt. Note wire run, water and drain lines.

